IPC_G6107-B0002P61D1806

Release Notes

IPC_G6107-B0002P61D1806

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_G6107-B0002P61D1806.

Acronym:

Acronym	Full Name	
IPC	IP Camera	

Content

1 Version Information	3
1.1 Version Number ······	3
1.2 Release History ·····	3
1.3 Version Mapping Table	3
2 Feature Change Description	4
3 Version Upgrade Description	3
4 Version Upgrade Procedure	3
4.1 Upgrade Overview ····································	5
4.1.1 Version Upgrade Environment	3
4.1.2 Version Upgrade Modes	7
4.2 Upgrade Procedure ······	7
4.2.1 Upgrade Through the Web	7
5 Version Upgrade Disclaimer ······	3

1 Version Information

1.1 Version Number

IPC_G6107-B0002P61D1806

1.2 Release History

Table1Released versions

Version No.	Basic Version No.		Released On	Remarks
IPC_G6107-B0002P61D1806	IPC_G6107-B0001P99D1806		2022-04-22	Improved release
Table2 Version mapping table				
Product Mapping Item Version No		No. (For External)		
NVR B3131P27				

1.3 Version Mapping Table

-

Product Series	IPC Series		
Series	IPC2128LR3 、 IPC3618LR3 、 IPC328LR3 、 IPC2124SR3 、 IPC325SR3 、 IPC3615SR3 、 IPC324SR3 、 IPC2125SR3 、 IPC3616LR3 、 IPC354SR3 、 IPC2324SBR5、IPC2325SBR5、IPC3534SR3、IPC3535SR3、IPC3634SR3、 IPC3635SR3、IPC		
Models	IPC2128LR3 series: IPC2128LR3-DPF28M-F、IPC2128LR3-DPF40M-F IPC2128LR3-PF40M-D		
	IPC3618LR3 series: IPC3618LR3-DPF28-F、IPC3618LR3-DPF40-F		
	IPC328LR3 series: IPC328LR3-DVSPF28-F、IPC328LR3-DVSPF40-F		
	IPC2124SR3 series: IPC2124SR3-DPF28M-F、IPC2124SR3-DPF40M-F		
	IPC3614SR3 series: IPC3614SR3-ADPF28-F、IPC3614SR3-ADPF40-F		
	IPC325SR3 series: IPC325SR3-DVPF28-F、IPC325SR3-DVPF40-F		

	IPC3615SR3 series:
	IPC3615SR3-ADPF28-F、IPC3615SR3-ADPF40-F
	IPC324SR3 series:
	IPC324SR3-DVPF28-F、IPC324SR3-DVPF40-F
	IPC2125SR3 series
	IPC2125SR3-ADPF28M-F、IPC2125SR3-ADPF40M-F
	IPC354SR3 series:
	IPC354SR3-ADNPF28-F
	IPC3616LR3 series:
	IPC3616LR3-DPF28M
	IPC2324SBR5 series:
	IPC2324SBR5-DPZ-F
	IPC2325SBR5 series:
	IPC2325SBR5-DPZ-F
	IPC3534SR3 series:
	IPC3534SR3-DVPZ-F、IPC3534SR3-DVNPZ-F
	IPC3535SR3 series:
	IPC3535SR3-DVPZ-F
	IPC3634SR3 series:
	IPC3634SR3-ADPZ-F
	IPC3635SR3 series:
	IPC3635SR3-ADPZ-F
	IPC series:
	IPC-T115-PF28-M、IPC-T118-DPF28-M
Target file name	IPC_G6107-B0002P61D1806.zip

2 Feature Change Description

P61D1806(IPC_G6107-B0002P61D1806):

ltem	Feature	Description
	Mandatory information	By default, user must fill in his/her mobile phone number
Newly added features		or email address when logging in to the Web interface for
		the first time.
Improved	None	None
features		
Deleted	None	None
features	None	None

P99D1806:

None

P97D1806:

None

P96D1806:

None

P91D1806:

None

P89D1806:

None

P87D1806:

ltem	Feature	Description
	Human body detection triggered actions	Add actions to trigger for human body detection: FTP, email, recording edge storage, image edge storage, alarm output.
	4MP product resolution change	Resolution of 4MP products changes from 2592*1520 to 2688*1520.
Newly added	,	Add intrusion detection alarm, and the actions to trigger are same as other alarms.
features	Strong password login	The default password changes to 123456 (admin was supported previously); After login, the user is required to change the password into a strong one. A strong password shall include at least nine characters comprising all three types: digits, letters, and special characters.
	WDR enable/disable sensitivity	Add WDR Open Sensitivity and WDR Close Sensitivity settings.
Improved features	None	None
Deleted features	None	None


3 Version Upgrade Description

None.

4 Version Upgrade Procedure

- 4.1 Upgrade Overview
- 4.1.1 Version Upgrade Environment
 - 1. Network Architecture for Upgrade

Figure1Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

4.1.2 Version Upgrade Modes

You can upgrade through the Web.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as admin (default password: 123456).
- (2) Click Setup>Maintenance>Device Maintenance. The Device Maintenance page is displayed.

Firmware Upgrade			
Upgrade File		Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
🗌 Enable Auto Restart	Each Day V 02:00:00	ОК	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_G6107-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

5 Version Upgrade Disclaimer

- By setting or installing this program in any way you agree to all of the following terms and conditions. Your downloading or using the program means you acknowledge your full understanding and acceptance of the following terms and conditions. If you do not agree to any of the following terms, you shall not use the program and you must cease installing and delete the program immediately.
- 2. The upgrade program is only applicable to the intended regions and product models. Before upgrade or update, please read the release notes carefully to make sure the program is applicable to your region and product model. You will be fully liable and responsible for all the consequences of device abnormality and related maintenance costs caused by your improper operations.
- 3. Uniview owns or is legally authorized to own all rights and IPRs (Intellectual Property Rights) of the program and the supplied release notes.
- 4. Software upgrades are for the optimization of product functions and do not mean there is defect.
- 5. You must strictly follow instructions in the release notes during the upgrade process, otherwise you are responsible for the possible consequences and related maintenance costs.
- 6. You shall not engage in any of the following activities, otherwise you would be liable for infringement and responsible for any adverse consequences arising therefrom.
- 6.1 Copy the program (exclude the reasonable and necessary copies for internal backups);
- 6.2 Exclude this statement when using the program or transfer the program to any third party;
- 6.3 Modify the program or its derivatives;
- 6.4 Reverse engineer, decompile or disassemble this program.
- 7. The program is only intended for authorized users. Its architecture, organization and source code are valuable trade secrets and confidential information owned by Uniview and its authorized parties. You agree not to provide or disclose any confidential information contained in or derived from the software to any third party. No part of this document may be excerpted, reproduced, or distributed in any form by any entity or individual without written consent from our company.